



CENTERLINE TOOLS



EXTERNAL TOOLS



INTERNAL TOOLS



• = TOOL TIP COMMAND POINT
F = DIMENSION FROM TOOL CATALOGUE